



# CREATOR

5762







1




2





3




4




5




6




7



8




9






10



11




12





1



2




3




4




5




6




7



8



9



1




2




2x


10



11




12






13




14





1



2



3



1



2




4



5




6



7




8



20

9




10




11



12



# 13



22



1x  
4160857



1x  
4161326



2x  
371001



1x  
302001



2x  
366601



1x  
4249506



1x  
302201



1x  
4287708



1x  
4287707



1x  
4200023



1x  
428626



2x  
4289255



1x  
4244363



2x  
3005744



4x  
4249039



2x  
4540386



4x  
4177932



2x  
4504371



1x  
4217722



2x  
4188771



2x  
4558595



1x  
4226179



1x  
4125278



2x  
4211477



2x  
4244368



3x  
4158355



2x  
4211496



3x  
4547035



1x  
4550011



1x  
4173332



1x  
4211406



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

[www.lego.com/service](http://www.lego.com/service) or dial



      : 00800 5346 5555

  : 1-800-422-5346



# CREATOR

5766



 [www.LEGO.com](http://www.LEGO.com)

©2011 The LEGO Group. 4623045 / 4623046

