




CREATOR

5865






1




2


2




3




4




5




6




7





8




9







10




11




12




1




2




3




4




13



14



15






1




2




3




4




5



6




7




8



9




10




11




1




2




12



13




14



15







1




2




3




4




5




6




7



8




1




2




3




9




10



11



12





2x
4558952



2x
242001



1x
4289272



1x
379501



2x
460026



1x
4124096



3x
241226



4x
4508215



1x
4107736



1x
4106356



3x
302328



2x
4272665



3x
371028



2x
302028



2x
4107637



1x
4522673



2x
4210828



2x
4167842



2x
4244362



2x
4260942



4x
4222960




1x
4211469



4x
4211525



2x
4215513



1x
4211406



2x
4225532



1x
4211356



2x
4211399



4x
4211765



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

www.lego.com/service or dial




: 00800 5346 5555

: 1-800-422-5346



CREATOR



©2009 The LEGO Group. 4582774

