



TECHNIC

42001



1



2




3





4






1




2





2x

3




4



2x


4






2x

5



4x


6





4x

7






6





2x

8







9



10



2x
3005740

2x
3005741



4x
4299119



6x
6004888



2x
4211483



2x
4211573



4x
4211622



1x
4211815



5x
4211639



1x
4211805




2x
4121610



6x
4121715



2x
4107081



1x
370526



2x
4281515



1x
6022768



1x
6022767



2x
4655123



2x
4544140



5x
4142865



4x
4514553



4x
4506553



2x
4560174



3x
4121667



2x
4142236



4x
6030286



4x
4184169




2x
4210857



2x
4210980



2x
4210851



2x
4210686




1x
4210668



1x
4223767



2x
6005331



6x
4560177



6x
4210667


Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



TECHNIC



42011



42010



42002



42004



42007





www.LEGOclub.com/Max



FREE*! GRATIS! GRATUIT !

*Paid subscription in Australia and New Zealand.
*Abonnement payant en Australie et Nouvelle-Zélande.



6043037 / 6043039

LEGO and the LEGO logo are
trademarks of the/son des marques
de commerce de/son marcas
registradas de LEGO Group.
©2013 The LEGO Group.

