



Инструкция ЛЕГО (Lego) 60097-9

CITY

60097



7 LEGO.com/city



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.








+




15



2x



1x




1

2



2x



1x

2



AVERTISSEMENT :


RISQUE D'ÉTOUFFEMENT. Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA:


PELIGRO DE ASFIXIA.

Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.






2x



2x

3



4




1x



1x

4






1x



1x

5



6




2x



1x

6






1x

1



4x



2






4x

3



1x

4





1x

5







2x

6


1



2




2x



2x

7






8


1



2



2x





1x



1x




2x

9



7






1x



2x


8





1x


9






2x


10





1x

11






2x



2x


12





2x


13





3x

14





1x



1x

15


1



2



3






1x



1x

16



1




2




3






2x


17





4x


18





4x

19






2x



2x

20


1




2




2x






1x

21





1





7x

2



1x

3





1x

4





1x

5



1x

6





1x


7





4x

8





4x

9





1x

10



22

