




CITY


7213




1



2









1




2




3



4



5



6







7



8




9





10






1






3




4





5






7







9



10




11






1




2




3




4



13







14




15





16



17




18




2x

1



2





3





2x

19





21





# CITY



7241



7942



7239



7208



7207



# CITY



3177



3178



3179



3180



3181



3182

**FREE! GRATIS! GRATUIT!**



**www.LEGOclub.com**



**00800 5346 5555\***        



**1-866-534-6258 • 1-877-518-5346**

US & Canada only

Canada seulement

\* Free phone. Mobile charges may apply. \* Numéro sans frais. Des frais peuvent s'appliquer avec les téléphones cellulaires. \* Geldfrei anrufen. Kosten für Anrufe aus Mobilfunknetzen können anfallen. \* Gratis telefonnummer vanaf vaste lijn. \* Deter est gratuit numere, dar du ringer Pro Postale Fin. \* Det är gratis, när du ringer från Post betalt Fin. \* Det är gratis, när du ringer från Post betalt Fin.



 [www.LEGO.com](http://www.LEGO.com)

VISIT THE WORLD'S  
BIGGEST LEGO® SHOP!

**www.LEGOshop.com**