







TECHNIC

9391






1




2



1:1






1x



2x

3

3



3

1:1





1x





1x

4





5



1:1






6


1




2













8



8




9





3

1:1





10






11



12



1:1



1x









1x



1x

13







2x

1x

4




14






15





16









17



18







1x



2x

19



1x

6



1x

1

6




6


1:1



2





3





2x

4



2x




2x





2x

5




2x



3


1:1


20





1x

21






22





1:1



23



24






2x



2x


25







58x

26





29x



2x



1





2




1:1



3




4





11


1:1




5




27



28





Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

www.lego.com/service or dial



00800 5346 5555 :

1-800-422-5346 :

